



SandStone™ Part 1 Basic Application

Make sure that the surface is well sealed by applying 2 coats of SetCoat®. Allow to dry at least overnight.

step 1. Apply a coat of SandStone™ using a roller in random thicknesses.

step 2. Allow the material to dry until there is no transfer to one's fingertips.

step 3. Using a Faux Effects® trowel, scrape the SandStone™ vertically to smooth out the material and allow the embedded particles to show through.

Allow to dry completely.

step 4. Scrape the finish one more time to remove any leftover loose material.

If desired, apply a color glaze to further enhance the SandStone™ effect (Video 2 SandStone™ part 2 Overglazed).

Tips:

Always make a sample to ensure the desired result.

*SetCoat® is recommended because it contains harder acrylics than other wall paints, which allows SandStone™ to be scraped.

2700 Industrial Avenue Two, Fort Pierce, Florida 34946

800-270-8871 □ www.fauxfx.com

©2020 Faux Effects International, Inc. All Rights Reserved

