



# WallSilk™ Basic Application

Products: WallSilk™, ShimmerCoat™

Tools: 3/8" nap roller, WallSilk Tools (14" 8" & 4")

step 1. Using a 3/8" roller apply an even and generous coat of WallSilk™.

step 2. Drag WallSilk Tool™ vertically or horizontally through the WallSilk™. Allow to dry for 24 hours.

step 3. Roll on a generous coat of ShimmerCoat™ to add shimmer and to protect.

Tips: Always make a sample to ensure desired results.

To replicate the raw silk look, use recommended base coat SetCoat® White.

Hand mix before each use.

Press a layer of plastic into can before replacing lid to keep unused product from crusting over.

Use the smaller tools to finish around windows and doors.

***View the WallSilk™ basic application video at [Fauxfx.com](http://Fauxfx.com)***



2700 Industrial Avenue Two, Fort Pierce, Florida 34946  
800-270-8871 • [www.fauxfx.com](http://www.fauxfx.com)  
©2020 Faux Effects International, Inc. All Rights Reserved

