



AquaStone[®] (Basic Application)

Products: AquaStone[®], SeatCoat Clear[®]

Tools: Faux Effects[®] Trowels, 1/4" Nap Roller, Pounce Brush, Spray Bottle, Sanding Block (Medium Grit)



Prep. Apply over a properly prepare substrate. Apply a coat of best quality latex paint or Faux Effects[®] SetCoat[®] in white. Let dry.

step 1. Thin AquaStone[®] with 10% water so it can be pounced on. When thinned properly, the loaded pounce brush will hold steep peaks.



step 2. Apply 1/8" thick layer of AquaStone[®] with a pounce brush creating high and low peaks of the material.

step 3. Spritz entire surface with a fine mist of water.



step 4. Using a Faux Effects[®] Trowel, with minimal pressure knock down the peaks to replicate embedded stone. Let dry (at least overnight).

step 5. Lightly sand the AquaStone[®] until any harsh abrasiveness is removed. This is a quick step. Sand just to make it feel smooth to the touch. Be sure to remove all dust after sanding.



step 6. Seal with SetCoat Clear[®]. Allow to dry at least overnight. Surface must be sealed to resist staining and to accept further finishing techniques.

